

General permanent fix roof anchor point configuration and layout.
This is a guide only.

NOTE: Every roof design is different to the next and requires a "Competent" installer to install the roof anchor points, access brackets and wire stroops in the correct locations, as per AS/ NZS1891.4:2009.

Roof Anchor points


Ladder access point

Wire connector stop


PRELIMINARY

DISCLAIMER

NORTH



Do not scale drawings manually or electronically



DATE REV ISSUE

CHECKED BY

PROJECT NAME:

NO REV TITLE
A005 G PROPOSED ROOF PLAN

PHASE SCALE
TD 1 : 100 @ A1

DATE