



General permanent fix roof anchor point configuration and layout.
This is a guide only.
NOTE: Every roof design is different to the next and requires a "Competent" installer to install the roof anchor points, access brackets and wire strots in the correct locations, as per AS/ NZS 1891.4:2009.

Generally the roof anchors MUST be spaced with equal distance from gutter line to next anchor point location

approx 6 meters

approx 6 meters

approx 6 meters

Roof Anchor points

Ladder access point

Wire connector strop

PRELIMINARY

DISCLAIMER Do not scale drawings manually or electronically.	NORTH 	DATE REV ISSUE	CHECKED BY	PROJECT NAME:	
				NO A005	REV G

